# Rosemount 8700 Series Magnetic Flowmeter Sensors





# **ROSEMOUNT**<sup>®</sup>

www.rosemount.com





#### **Quick Installation Guide** 00825-0100-4727. Rev CC January 2013

# Rosemount 8700 Series

© 2013 Rosemount Inc. All rights reserved. All marks property of owner.

Emerson Process Management Emerson Process Emerson FZE Rosemount Flow 7070 Winchester Circle Boulder, CO 80301 Tel (USA) 800 522 6277 Tel (International) +1 (303) 527 5200 T +31 (0) 318 495555 Fax +971 4 886 5465 T (65) 6777 8211 F +1 (303) 530 8459

Management Flow P.O. Box 17033 Neonstraat 1 6718 WX Ede The Netherlands F +31 (0) 318 495556

Jebel Ali Free Zone Dubai UAE Tel +971 4 811 8100

Emerson Process Management Asia Pacific Private Limited 1 Pandan Crescent Singapore 128461 F (65) 6777 0947/65 6777 0743

# **M** IMPORTANT NOTICE

This document provides basic installation guidelines for the Rosemount<sup>®</sup> 8700 Series Sensors. It does not provide instructions for detailed configuration, diagnostics, maintenance, service, troubleshooting, explosion-proof, flameproof, or intrinsically safe (I.S.) installations. Refer to the Rosemount 8700 reference manual (document number 00809-0100-4727) for more instructions. The manual and this QIG are also available electronically on www.rosemount.com.

# **WARNING**

#### Failure to follow these installation guidelines could result in death or serious injury:

Installation and servicing instructions are for use by gualified personnel only. Do not perform any servicing other than that contained in the operating instructions, unless gualified. Verify that the operating environment of the sensor and transmitter is consistent with the appropriate FM, CSA, ATEX, or IECEx approval.

# **WARNING**

The sensor liner is vulnerable to handling damage. Never place anything through the sensor for the purpose of lifting or gaining leverage. Liner damage can render the sensor useless.

To avoid possible damage to the sensor liner ends, do not use metallic or spiral-wound gaskets. If frequent removal is anticipated, take precautions to protect the liner ends. Short spool pieces attached to the sensor ends are often used for protection.

Correct flange bolt tightening is crucial for proper sensor operation and life. All bolts must be tightened in the proper sequence to the specified torgue limits. Failure to observe these instructions could result in severe damage to the sensor lining and possible sensor replacement.

# **WARNING**

Rosemount 8705 Magnetic Flowtube units ordered with non-standard paint options may be subject to electrostatic discharge.

To avoid electrostatic charge build-up, do not rub the meter body with a dry cloth or clean with solvents.

# STEP 1: HANDLING

Handle all parts carefully to prevent damage. Whenever possible, transport the system to the installation site in the original shipping containers. PTFE-lined sensors are shipped with end covers that protect it from both mechanical damage and normal unrestrained distortion. Remove the end covers just before installation.



# STEP 2: MOUNTING

### **Upstream/Downstream Piping**

To ensure specification accuracy over widely varying process conditions, install the sensor a minimum of five straight pipe diameters upstream and two pipe diameters downstream from the electrode plane (see Figure 2).

Figure 2. Upstream and Downstream Straight Pipe Diameters



Installations with reduced straight runs from 0 to five pipe diameters are possible. In reduced straight pipe run installations, performance will shift to as much as 0.5% of rate. Reported flow rates will still be highly repeatable.

### Flow Direction

The sensor should be mounted so the FORWARD end of the flow arrow, shown on the sensor identification tag, points in the direction of flow through the sensor.

#### Sensor Location

The sensor should be installed in a location that ensures the sensor remains full during operation. Vertical installation allows upward process fluid flow and keeps the cross-sectional area full, regardless of flow rate. Horizontal installation should be restricted to low piping sections that are normally full.



#### Sensor Orientation

The electrodes in the sensor are properly orientated when the two measurement electrodes are in the 3 and 9 o'clock positions or within 45° from the vertical, as shown on the right of Figure 4. Avoid any mounting orientation that positions the top of the sensor at 90° from the vertical position as shown on the left of Figure 4.



# **STEP 3: INSTALLATION**

## Flanged Sensors

### Gaskets

The sensor requires a gasket at each of its connections to adjacent devices or piping. The gasket material selected must be compatible with the process fluid and operating conditions. Metallic or spiral-wound gaskets can damage the liner. Gaskets are required on each side of a grounding ring. All other applications (including sensors with lining protectors or a grounding electrode) require only one gasket on each end connection.

Figure 5. Flanged gasket placement



### Flange Bolts

### NOTE

Do not bolt one side at a time. Tighten each side simultaneously. Example:

- 1. Snug left
- 2. Snug right
- 3. Tighten left
- 4. Tighten right

Do not snug and tighten the upstream side and then snug and tighten the downstream side. Failure to alternate between the upstream and downstream flanges when tightening bolts may result in liner damage.

Suggested torque values by sensor line size and liner type are listed in Table 1 for ASME B16.5 and Table 2 for EN flanges. Consult the factory if the flange rating of the sensor is not listed. Tighten flange bolts on the upstream side of the sensor in the incremental sequence shown in Figure 6 to 20 percent of the suggested torque values. Repeat the process on the downstream side of the sensor. For sensors with more or less flange bolts, tighten the bolts in a similar crosswise sequence. Repeat this entire tightening sequence at 40, 60, 80, and 100 percent of the suggested torque values or until the leak between the process and sensor flanges stop.

If leakage has not stopped at the suggested torque values, the bolts can be tightened in additional 10 percent increments until the joint stops leaking, or until the measured torque value reaches the maximum torque value of the bolts. Practical consideration for the integrity of the liner often leads the user to distinct torque values to stop leakage due to the unique combinations of flanges, bolts, gaskets, and sensor liner material.

Check for leaks at the flanges after tightening the bolts. Failure to use the correct tightening methods can result in severe damage. Sensors require a second tightening 24 hours after the initial installation. Over time, sensor liner materials may deform under pressure.



Table 1.	Suggested Flange E	Bolt Torque	Values for	Rosemount 8705	and 8707 High-Signa	I Sensors
	00 0				0 0	

		PTFE/ETFE/PFA liners		Polyurethane/Neop	rene/Adiprene liner
Size Code	Line Size	Class 150 (pound-feet)	Class 300 (pound-feet)	Class 150 (pound-feet)	Class 300 (pound-feet)
005	0.5 in. (15 mm)	8	8	-	-
010	1 in. (25 mm)	8	12	-	-
015	1.5 in. (40 mm)	13	25	7	18
020	2 in. (50 mm)	19	17	14	11
025	2.5 in. (65mm)	22	24	17	16
030	3 in. (80 mm)	34	35	23	23
040	4 in. (100 mm)	26	50	17	32
050	5 in. (125mm)	36	60	25	35
060	6 in. (150mm)	45	50	30	37
080	8 in. (200 mm)	60	82	42	55
100	10 in. (250 mm)	55	80	40	70
120	12 in. (300 mm)	65	125	55	105
140	14 in. (350 mm)	85	110	70	95
160	16 in. (400 mm)	85	160	65	140
180	18 in. (450 mm)	120	170	95	150
200	20 in. (500 mm)	110	175	90	150
240	24 in. (600 mm)	165	280	140	250
300	30 in. (750 mm)	195	415	165	375
360	36 in. (900 mm)	280	575	245	525

		Polyurethane, Linatex, Adiprene and Neoprene Liners					
		PN10	PN 16	PN 25	PN 40		
Size Code	Line Size	(Newton-meter)	(Newton-meter)	(Newton-meter)	(Newton-meter)		
005	0.5-inch (15 mm)				10		
010	1 inch (25 mm)				20		
015	1.5 inch (40 mm)				50		
020	2 inch (50 mm)				60		
025	2.5 inch (65 mm)				50		
030	3 inch (80 mm)				50		
040	4 inch (100 mm)		50		70		
050	5.0 inch (125 mm)		70		100		
060	6 inch (150mm)		90		130		
080	8 inch (200 mm)	130	90	130	170		
100	10 inch (250 mm)	100	130	190	250		
120	12 inch (300 mm)	120	170	190	270		
140	14 inch (350 mm)	160	220	320	410		
160	16 inch (400 mm)	220	280	410	610		
180	18 inch (450 mm)	190	340	330	420		
200	20 inch (500 mm)	230	380	440	520		
240	24 inch (600 mm)	290	570	590	850		

#### **Quick Installation Guide**

00825-0100-4727, Rev CC January 2013

# Rosemount 8700 Series

		Polyurethane, Linatex, Adiprene and Neoprene Liners				
		PN 10	PN 16	PN 25	PN 40	
Size Code	Line Size	(Newton-meter)	(Newton-meter)	(Newton-meter)	(Newton-meter)	
010	1 inch (25 mm)				20	
015	1.5 inch (40 mm)				30	
020	2 inch (50 mm)				40	
025	2.5 inch (65 mm)				35	
030	3 inch (80 mm)				30	
040	4 inch (100 mm)		40		50	
050	5.0 inch (125 mm)		50		70	
060	6 inch (150 mm)		60		90	
080	8 inch (200 mm)	90	60	90	110	
100	10 inch (250 mm)	70	80	130	170	
120	12 inch (300 mm)	80	110	130	180	
140	14 inch (350 mm)	110	150	210	280	
160	16 inch (400 mm)	150	190	280	410	
180	18 inch (450 mm)	130	230	220	280	
200	20 inch (500 mm)	150	260	300	350	
240	24 inch (600 mm)	200	380	390	560	

Table 2. (continued) Flange Bolt Torque and Bolt Load Specifications for 8705 (EN 1092-1)

## Wafer Sensors

### Gaskets

The sensor requires a gasket at each of its connections to adjacent devices or piping. The gasket material selected must be compatible with the process fluid and operating conditions. Metallic or spiral-wound gaskets can damage the liner. Gaskets are required on each side of a grounding ring. See Figure 7 below.

Figure 7. Wafer gasket placement



#### Alignment

- On 1.5 through 8-inch (40 through 200 mm) line sizes. Rosemount strongly recommends installing the alignment spacers provided to insure proper centering of the wafer sensor between the process flanges. Sensor sizes of 0.15, 0.30, 0.5 and 1 in. (4 through 25 mm), do not require alignment spacers.
- Insert studs for the bottom side of the sensor between the pipe flanges and center the alignment spacer in the middle of the stud. See Figure 7 for the bolt hole locations recommended for the spacers provided. Stud specifications are listed in Table 3.
- 3. Place the sensor between the flanges. Make sure that the alignment spacers are properly centered on the studs. For vertical flow installations slide the o-ring over the stud to keep the spacer in place. See Figure 7. To ensure the spacers match the flange size and class rating for the process flanges see Table 4 on page 11.
- 4. Insert the remaining studs, washers, and nuts.
- 5. Tighten to the torque specifications shown in Table 5 on page 12. Do not overtighten the bolts or the liner may be damaged.

Table 3.	Stud	Specifications	
No	mina	L Concor Sizo	

. .

Nominal Sensor Size	Stud Specifications
0.15 – 1 in. (4 – 25 mm)	316 SST ASTM A193, Grade B8M Class 1 threaded mounted studs
1.5 – 8 in. (40 – 200 mm)	CS, ASTM A193, Grade B7, threaded mounting studs

### NOTE

Sensor sizes of 0.15, 0.30, and 0.5 in. mount between AMSE 1/2-inch flanges. Using carbon steel bolts on sensor sizes of 0.15, 0.30, 0.15- through 1-in. (4 through 25 mm), rather than the required stainless steel bolts, will degrade the flow sensor measurement.

#### **Quick Installation Guide**

00825-0100-4727, Rev CC January 2013

Rosemount Alignment Spacer Table				
	Line	Size		
Dash No.	(in)	(mm)	Flange Rating	
0A15	1.5	40	JIS 10K-20K	
0A20	2	50	JIS 10K-20K	
0A30	3	80	JIS 10K	
0B15	1.5	40	JIS 40K	
AA15	1.5	40	ANSI - 150#	
AA20	2	50	ANSI - 150#	
AA30	3	80	ANSI - 150#	
AA40	4	100	ANSI - 150#	
AA60	6	150	ANSI - 150#	
AA80	8	200	ANSI - 150#	
AB15	1.5	40	ANSI - 300#	
AB20	2	50	ANSI - 300#	
AB30	3	80	ANSI - 300#	
AB40	4	100	ANSI - 300#	
AB60	6	150	ANSI - 300#	
AB80	8	200	ANSI - 300#	
AB15	1.5	40	ANSI - 300#	
AB20	2	50	ANSI - 300#	
AB30	3	80	ANSI - 300#	
AB40	4	100	ANSI - 300#	
AB60	6	150	ANSI - 300#	
AB80	8	200	ANSI - 300#	
DB40	4	100	DIN - PN10/16	
DB60	6	150	DIN - PN10/16	
DB80	8	200	DIN - PN10/16	
DC80	8	100	DIN - PN25	
DD15	1.5	150	DIN - PN10/16/25/40	
DD20	2	50	DIN - PN10/16/25/40	
DD30	3	80	DIN - PN10/16/25/40	
DD40	4	100	DIN - PN25/40	
DD60	6	150	DIN - PN25/40	
DD80	8	200	DIN - PN40	
RA80	8	200	AS40871-PN16	
RC20	2	50	AS40871-PN21/35	
RC30	3	80	AS40871-PN21/35	
RC40	4	100	AS40871-PN21/35	
RC60	6	150	AS40871-PN21/35	
RC80	8	200	AS40871-PN21/35	

To order an Alignment Spacer Kit (qty 3 spacers) use p/n 08711-3211-xxxx along with the Dash No. above.

### Flange Bolts

Wafer sensors require threaded studs. See Figure 6 on page 7 for torque sequence. Always check for leaks at the flanges after tightening the flange bolts. All sensors require a second torquing 24 hours after initial flange bolt tightening.

Size Code Line Size Pound-feet Newton-meter 15F 0.15 inch (4 mm) 5 7 30F 0.30 inch (8 mm) 5 7 005 0.5 inch (15 mm) 5 7 14 010 1 inch (25 mm) 10 015 1.5 inch (40 mm) 15 20 020 2 inch (50 mm) 25 34 030 3 inch (80 mm) 40 54 040 4 inch (100 mm) 30 41 060 6 inch (150 mm) 50 68 080 8 inch (200 mm) 70 95

### Table 5. Rosemount 8711 Torque Specifications

## Sanitary Sensors

#### Gaskets

The sensor requires a gasket at each of its connections to adjacent devices or piping. The gasket material selected must be compatible with the process fluid and operating conditions. Gaskets are supplied between the IDF fitting and the process connection fitting, such as a Tri-Clamp fitting, on all Rosemount 8721 Sanitary sensors except when the process connection fitting.

### Alignment and Bolting

Standard plant practices should be followed when installing a magmeter with sanitary fittings. Unique torque values and bolting techniques are not required. Figure 8. Rosemount 8721 Sanitary Installation



00825-0100-4727, Rev CC January 2013

# STEP 4: GROUNDING

Use Table 6 to determine which process grounding option to follow for proper installation. The sensor case should be earth grounded in accordance with national and local electrical codes. Failure to do so may impair the protection provided by the equipment.

Table 6. Process Grounding Installation

Process Grounding Options					
Type of Pipe	Grounding Straps	Grounding Rings	Grounding Electrode	Lining Protectors	
Conductive Unlined Pipe	See Figure 9	Not Required	Not Required	See Figure 10	
Conductive Lined Pipe	Insufficient Grounding	See Figure 10	See Figure 9	See Figure 10	
Non-Conductive Pipe	Insufficient Grounding	See Figure 11 on page 14	See Figure 12 on page 14	See Figure 11 on page 14	





# Quick Installation Guide

00825-0100-4727, Rev CC January 2013

# Rosemount 8700 Series



# STEP 5: WIRING

This wiring section covers the connection between the transmitter and sensor, the 4-20 mA loop, and supplying power to the transmitter. Follow the conduit information, cable requirements, and disconnect requirements in the sections below.

## **Conduit Ports and Connections**

Both the sensor and transmitter junction boxes have ports for <sup>1</sup>/<sub>2</sub>-inch NPT conduit connections with optional CM20 or PG 13.5 connections available. These connections should be made in accordance with national, local, and plant electrical codes. Unused ports should be sealed with metal plugs. Proper electrical installation is necessary to prevent errors due to electrical noise and interference. Separate conduits are not necessary for the coil drive and signal cables, but a dedicated conduit line between each transmitter and sensor is required. Shielded cable must be used for best results in electrically noisy environments. When preparing all wire connections, remove only the insulation required to fit the wire completely under the terminal connection. Removal of excessive insulation may result in an unwanted electrical short to the transmitter housing or other wire connections. For flanged sensors installed into an application requiring IP68 protection, sealed cable glands, conduit, and conduit plugs that meet IP68 ratings are required. Option codes are available to provide a pre-wired potted and sealed junction box to prevent the ingress of water. These options still require the use of sealed conduits to meet IP68 protection requirements.

### **Conduit Requirements**

A single dedicated conduit run for the coil drive and signal cable is needed between the sensor and the remote transmitter. See Figure 13. Bundled cables in a single conduit are likely to create interference and noise problems in the system. Use one set of cables per conduit run.



Run the appropriate size cable through the conduit connections in your magnetic flowmeter system. Run the power cable from the power source to the transmitter. Run the coil drive and signal cables between the flowmeter sensor and transmitter.

- Installed signal wiring should not be run together and should not be in the same cable tray as AC or DC power wiring.
- · Device must be properly grounded or earthed according to local electric codes.
- Rosemount combination cable part number 08732-0753-1003 (ft) or 08732-0753-2004 (m) is required to be used to meet EMC requirements.

#### **Transmitter to Sensor Wiring**

The transmitter can be integral to the sensor or remotely mounted following the wiring instructions.

#### **Remote Mount Cable Requirements and Preparation**

For installations using the individual coil drive and signal cable, lengths should be limited to less than 1,000 feet (300 meters). Equal length cable is required for each. See Table 7 on page 17.

For installations using the combination coil drive and signal cable, lengths should be limited to less than 330 feet (100 meters). See Table 7 on page 17.

Prepare the ends of the coil drive and signal cables as shown in Figure 14. Limit the unshielded wire length to 1-inch on both the coil drive and signal cables. Any unsheathed wire should be wrapped with proper insulation. Excessive lead length or failure to connect cable shields can create electrical noise resulting in unstable meter readings.

#### Figure 14. Cable Preparation Detail



Cable Shield

To order cable specify length as quantity desired. 25 feet = Qty (25) 08732-0753-1003

#### Table 7. Cable Requirements

Description	Length	Part Number
Coil Drive Cable (14 AWG) Belden 8720, Alpha 2442 or equivalent	ft m	08712-0060-0001 08712-0060-2013
Signal Cable (20 AWG) Belden 8762, Alpha 2411 or equivalent	ft m	08712-0061-0001 08712-0061-2003
Combination Cable Coil Drive Cable (18 AWG) and Signal Cable (20 AWG)	ft m	08732-0753-1003 08732-0753-2004

# WARNING

Potential Shock Hazard Across Terminals 1 & 2 (40Vac).

#### Wiring the Transmitter to the Sensor

When using individual cables for coil drive and signal refer to Table 8. If using the combination coil drive and signal cable refer to Table 9. See Figure 15 on page 18 for transmitter specific wiring diagrams.

- 1. Connect the coil drive cable using terminals 1, 2, and 3 (ground).
- 2. Connect the signal cable using terminals **17**, **18**, and **19**

#### Table 8. Individual Coil and Signal Cables

Transmitter Terminal	Sensor Terminal	Wire Gauge	Wire Color
1	1	14	Clear
2	2	14	Black
3 or Ground	3 or Ground	14	Shield
17	17	20	Shield
18	18	20	Black
19	19	20	Clear

#### Table 9. Combination Coil and Signal Cable

Transmitter Terminal	Sensor Terminal	Wire Gauge	Wire Color
1	1	18	Red
2	2	18	Green
3 or Ground	3 or Ground	18	Shield
17	17	20	Shield
18	18	20	Black
19	19	20	White

Figure 15. Remote Mount Wiring Diagrams





#### NOTE

When using the Rosemount supplied combination cable, the signal wires for terminals 18 and 19 contain an addition shield wire. These two shield wires should be tied with the main shield wire at terminal 17 at the sensor terminal block and cut back to the insulation in the transmitter junction box. See Figure 16.





#### Integral Mount Transmitters

The interconnecting wire harness for an integral mount transmitter is installed at the factory. See Figure 17. Do not use cable other than that supplied by Emerson Process Management, Rosemount, Inc.

#### Figure 17. 8732E Integral Mount Wiring Diagram



### Connecting the 4–20 mA Analog Signal

#### Cabling considerations

If possible, use individually shielded twisted pair cable, either in single pair or multi-pair varieties. Unshielded cables may be used for short distances, provided ambient noise and cross-talk will not adversely impact communication. The minimum conductor size is 0.51mm diameter (#24 AWG) for cable runs less than 1,500 meters (@ 5,000 ft.) and 0.81mm diameter (#20 AWG) for longer distances. Resistance in the loop must be 1000 ohms or less.

The 4–20 mA analog output loop signal may be powered internally or externally. The default position of the internal/external analog power switch is in the internal position. The user-selectable power supply switch is located on the electronics board.

#### Quick Installation Guide 00825-0100-4727, Rev CC January 2013

# Rosemount 8700 Series

**8732E** - connect negative (-)DC to Terminal 1 and positive (+)DC to Terminal 2. See Figure 18.

Figure 18. 8732E Analog Signal Wiring Diagram



**8712E** - connect negative (-)DC to Terminal 8 and positive (+)DC to Terminal 7. See Figure 19.

#### Figure 19. 8712E Analog Signal Wiring Diagram



#### Internal Power Source

The 4–20 mA analog signal loop is powered from the transmitter itself.

#### **External Power Source**

The 4–20 mA analog signal loop is powered from an external power source. HART multidrop installations require a 10–30 V DC external analog power source.

#### NOTE:

If a HART Field Communicator or control system will be used, it must be connected across a minimum of 250 ohms resistance in the loop.

To connect any of the other output options (pulse output and/or digital input/output), consult the comprehensive product manual.

#### **Powering the Transmitter**

The 8712E / 8732E transmitter is designed to be powered by 90-250 Vac, 50–60 Hz or 12–42 Vdc. Before connecting power to the Rosemount 8712E / 8732E, consider the following standards and be sure to have the proper power supply, conduit, and other accessories. Wire the transmitter according to national, local, and plant electrical requirements for the supply voltage. See Figure 20.

#### Figure 20. DC Power Supply Current Requirements



#### **Supply Wire Requirements**

Use 12 to 18 AWG wire rated for the proper temperature of the application. For connections in ambient temperatures above 140 °F (60 °C), use a wire rated for 176 °F (80 °C). For ambient temperatures greater than 176 °F (80 °C), use a wire rated for 230 °F (110 °C). For DC powered transmitters with extended cable lengths, verify that there is a minimum of 12 V DC at the terminals of the transmitter.

#### Disconnects

Connect the device through an external disconnect or circuit breaker. Clearly label the disconnect or circuit breaker and locate it near the transmitter and per local electrical control.

#### Installation Category

The installation category for the 8712E / 8732E is (Overvoltage) Category II.

#### **Overcurrent Protection**

The Rosemount 8712E / 8732E flowmeter transmitter requires overcurrent protection of the supply lines. Maximum ratings of overcurrent devices are shown in Table 10.

#### Table 10. Overcurrent Limits

Power System	Fuse Rating	Manufacturer
95-250 V AC	2 Amp, Quick Acting	Bussman AGC2 or Equivalent
12-42 V DC	3 Amp, Quick Acting	Bussman AGC3 or Equivalent

# Quick Installation Guide 00825-0100-4727, Rev CC

January 2013

#### 8732E Power Supply

For AC power applications (90-250 VAC, 50-60 Hz) connect AC Neutral to terminal 9 (AC N/L2) and connect AC Line to terminal 10 (AC/L1). For DC power applications connect negative to terminal 9 (DC -) and positive to terminal 10 (DC +). Units powered by 12-42 V DC power supply may draw up to 1 amp of current. See Figure 21 for terminal block connections.





#### 8712E Power Supply

For AC power applications (90-250 VAC, 50-60 Hz) connect AC Neutral to terminal N and connect AC Line to terminal L1. For DC power applications, connect negative to terminal N (DC -) and positive to terminal L1 (DC +). Ground the transmitter cage via the grounding stud located on the bottom of the transmitter housing. Units powered by 12-42 V DC powersupply may draw up to 1 amp of current. See Figure 21 for terminal block connections.





# Cover Jam Screw (8732E Only)

For transmitter housings shipped with a cover jam screw, the screw should be properly installed once the transmitter has been wired and powered up. Follow these steps to install the cover jam screw:

- 1. Verify that the cover jam screw is completely threaded into the housing.
- 2. Install the transmitter housing cover and verify that the cover is tight against the housing.
- 3. Using an M4 hex wrench, loosen the jam screw until it contacts the transmitter cover.
- Turn the jam screw an additional <sup>1</sup>/<sub>2</sub> turn counterclockwise to secure the cover. (Note: Application of excessive torque may strip the threads.)
- 5. Verify that the cover cannot be removed.

January 2013

# **Product Certifications**

### **Approved Manufacturing Locations**

Rosemount Inc. - Eden Prairie, Minnesota, USA

Fisher-Rosemount Technologias de Flujo, S.A. de C.V. — Chihuahua Mexico

Emerson Process Management Flow - Ede, The Netherlands

Asia Flow Technology Center - Nanjing, China

## **European Directive Information**

The EC Declaration of Conformity can be found on page 34. The most recent revision can be found at www.rosemount.com.

### Type n protection type in accordance with EN50021

 $\triangle$ 

• Closing of entries in the device must be carried out using the appropriate EEx e or EEx n metal cable gland and metal blanking plug or any appropriate ATEX approved cable gland and blanking plug with IP66 rating certified by an EU approved certification body.

### Complies with Essential Health and Safety Requirements:

EN 61241-0: 2006 EN 61241-1: 2004

## European Pressure Equipment Directive (PED) (97/23/EC)

# Rosemount 8705 and 8707 Magnetic Flowmeter sensors in line size and flange combinations:

Line Size: 1<sup>1</sup>/<sub>2</sub> in. - 24 in. with all DIN flanges and ANSI 150 and ANSI 300 flanges. Also available with ANSI 600 flanges in limited line sizes.

Line Size: 30 in. - 36 in. with AWWA 125 flanges QS Certificate of Assessment - EC No. 59552-2009-CE-HOU-DNV Module H Conformity Assessment

## Rosemount 8711 Magnetic Flowmeter Sensors

#### Line Sizes: 1.5, 2, 3, 4, 6, and 8 in.

QS Certificate of Assessment - EC No. 59552-2009-CE-HOU-DNV Module H Conformity Assessment

### Rosemount 8721 Sanitary Magmeter Sensors

in line sizes of 1<sup>1</sup>/<sub>2</sub> in. and larger:

Module H Conformity Assessment

#### All other Rosemount 8705/8707/8711/8721

#### Sensors —

in line sizes of 1 in. and less: Sound Engineering Practice

Sensors that are SEP are outside the scope of PED and cannot be marked for compliance with PED.

Mandatory CE-marking for sensors in accordance with Article 15 of the PED can be found on the sensor body ( CC 0575).

Sensor category I is assessed for conformity per module A procedures.

Sensor categories II – III, use module H for conformity assessment procedures.

#### Other important guidelines

Only use new, original parts.

To prevent the process medium escaping, do not unscrew or remove process flange bolts, adapter bolts or bleed screws during operation.

Maintenance shall only be done by qualified personnel.

#### CE CE Marking

Compliance with all applicable European Union Directives. (Note: **C€** Marking is not available on Rosemount 8712H).

#### **Sensor Approval Information**

	Rosemo Ser	unt 8705 Isor	Rosemo Ser	unt 8707 Isor	Rosemo Ser	ount 8711 Isor	Rosemount 8721 Sensors
Approval Codes	For Non Flammable Fluids	For Flammable Fluids	For Non Flammable Fluids	For Flammable Fluids	For Non Flammable Fluids	For Flammable Fluids	For Non Flammable Fluids
NA	•						•
N0	•		•		•		
ND	•		•	•	•	•	•
N1	•	•			•	•	
N5	•	•	•	•	•	•	
N7	•	•			•	•	
NF	•				•	•	
E1	•	•			•	•	
E2	•	•			•	•	
E3	•	•			•	•	
E5 <sup>(1)</sup>	•	•			•	•	
E8	•	•			•	•	
E9	•	•			•	•	
EB	•	•			•	•	
EK	•	•			•	•	
EM	•	•			•	•	
EP	•	•			•	•	
KD	•	•			•	•	

(1) Available in line sizes up to 8 in. (200 mm) only.

### **Quick Installation Guide**

00825-0100-4727, Rev CC January 2013

#### North American Certifications

#### Factory Mutual (FM)

- N0 Non-incendive for Class I, Division 2, Groups A, B, C, and D non-flammable fluids (8705/8711 T5 at 60 °C; 8707 T3C at 60 °C), and Dust-ignition proof Class II/III, Division 1, Groups E, F, and G (8705/8711 T6 at 60 °C; 8707 T3C at 60 °C) Hazardous locations; Enclosure Type 4X
- N0 8721 Hygienic Sensor Factory Mutual (FM) Ordinary Location; CE Marking; 3-A Symbol Authorization #1222; EHEDG Type EL
- N5 Non-incendive for Class I, Division 2, Groups A, B, C, and D; with intrinsically safe electrodes for use on flammable fluids (8705/8711 T5 at 60 °C; 8707 T3C at 60 °C), and Dust-ignition proof Class II/III, Division 1, Groups E, F, and G (8705/8711 T6 at 60 °C; 8707 T3C at 60 °C) Hazardous locations; Enclosure Type 4X
- E5 Explosion proof for Class I, Division 1, Groups C and D (8705/8711 T6 at 60 °C), and Dust-ignition proof Class II/III, Division 1, Groups E, F, and G (8705/8711 T6 at 60 °C), and non-incendive for Class I, Division 2, Groups A, B, C, and D flammable fluids (8705/8711 T5 at 60 °C) Hazardous locations; Enclosure Type 4X

#### Canadian Standards Association (CSA)

- N0 Non-incendive for Class I, Division 2, Groups A, B, C, and D non-flammable fluids (8705/8711 T5 at 60 °C; 8707 T3C at 60 °C), and Dust-ignition proof Class II/III, Division 1, Groups E, F, and G (8705/8711 T6 at 60 °C; 8707 T3C at 60 °C) Hazardous locations; Enclosure Type 4X
- 8721 Hygienic Sensor
   Canadian Standards Association (CSA) Ordinary Location;
   CE Marking; 3-A Symbol Authorization #1222;
   EHEDG Type EL

#### **European Certifications**

#### Installation Instructions

The cable and conduit entry devices and blanking elements shall be of a certified IP6x type, suitable for the conditions of use and correctly installed. At maximum ambient temperatures or at process temperatures above 60 °C heat resistant cables with a temperature rating of at least 90 °C shall be used.

The surface temperature of 105 °C is based on a maximum ambient temperature of 65 °C. When the process temperature is higher than the maximum ambient temperature (up to a maximum of 180 °C), the surface temperature will be the process temperature plus 40 °K.

N1 ATEX Non-Sparking/Non-incendive Certificate No: KEMA02ATEX1302X O II 3G EEx nA [L] IIC T3... T6 (-20 °C  $\leq$  T<sub>a</sub>  $\leq$  +65 °C)

#### Special condition for safe use (x):

The relation between ambient temperature, process temperature, and temperature class is to be taken from Table 13 on page 31. The electrical data is to be taken from Table 14 on page 33.

#### KD, E1

#### Special condition for safe use (x):

The relation between ambient temperature, process temperature and temperature class is to be taken from Table 13 on page 31. The electrical data is to be taken from Table 14 on page 33.

#### Installation Instructions

At ambient temperatures above 50 °C, heat resistant cables with a temperature rating of at least 90 °C shall be used.

A fuse with a rating of maximum 0.7 A according to IEC 60127-1 shall be included in the coil excitation circuit if the sensors are used with other flow transmitters.

#### International Certifications

N7 IECEx Type 'n'

Certificate Number: IECEx DEK 11.0094X Ex nA nL IIC T3...T5 Gc IP66 (-50 °C  $\leq T_a \leq +60$  °C) (see Table 14 on page 33 for relationship between process temperature and temperature code.)

#### Special Condition for safe use (x):

The relation between ambient temperature, process temperature, temperature class, orientation of the junction box and flowtube mounting is to be taken from Table 14 on page 33. The equipment shall only be used with a flow transmitter that uses a current-control coil excitation circuit that complies with the Electrical Data in Table 15 on page 33. When used with an integrally mounted transmitter, exceeding of the temperature limits of the transmitter by the influence of ambient and process temperature shall be prevented.

Units marked with "Warning: Electrostatic Charging Hazard" may use non-conductive paint thicker than 0.2 mm. Precautions shall be taken to avoid ignition due to electrostatic charge on the enclosure.

#### Installation Instructions

At an ambient temperature greater than 140 °F/60 °C, and a process temperature above or equal to 140 °F/60 °C, the flowmeter must be used with heat-resistant cables with a temperature rating of at least 194 °F/90 °C. At a process temperature greater than 100 °C, the flowmeter shall be used with heat-resistant cables with a temperature rating of at least 212 °F/100 °C. Cable entry devices and blanking elements shall be of an Ex e or Ex n certified type, with a minimum rating of IP54.

#### NF IECEx Dust

Certificate Number: IECEx KEM 09.0078 Ex tD A20 IP6x T105 °C (-50  $\leq$  T<sub>a</sub>  $\leq$  65 °C)

#### Installation Instructions:

The cable and conduit entry devices and blanking elements shall be of a certified IP6x type, suitable for the conditions of use and correctly installed. At maximum ambient temperatures or at process temperatures above 60 °C heat resistant cables with a temperature rating of at least 90 °C shall be used.

The surface temperature of 105 °C is based on a maximum ambient temperature of 65 °C. When the process temperature is higher than the maximum ambient temperature (up to a maximum of 180 °C), the surface temperature will be the process temperature plus 40 °K.

#### NEPSI - China

#### E3, EP

NEPSI Increased Safety with IS Electrodes Certificate No. GYJ071360X Ex e ia IIC T3...T6 (-20 °C  $\leq$  Ta  $\leq$  +65 °C) (see Table 12 on page 30)

#### InMetro - Brazil

#### E2, EB

NCC Increased Safety with IS Electrodes Certificate No. NCC 12.1177 X Ex e ia IIC T3...T6 (-20 °C ≤ Ta ≤ +65 °C) (see Table 12 on page 30)

#### KOSHA - Korea

#### E9, EK

KOSHA Increased Safety with IS Electrodes Certificate No. 2005-2232-QIX Ex e ia IIC T3 T6 (-20 °C  $\leq$  Ta  $\leq$  +65 °C) (see Table 12 on page 30)

#### Table 11. Electrical Data

Rosemount 8705 and 8	711 Sensors
Coil excitation circuit:	40 V, 0,5 A, 20 W maximum
Electrode circuit:	in type of explosion protection intrinsic safety EEx ia IIC, U <sub>i</sub> = 5 V, I <sub>i</sub> = 0.2 mA, $ P_i = 1 \text{ mW}$ , U <sub>m</sub> = 250 V

Table 12. Relation between ambient temperature, process temperature, and temperature class<sup>(1)</sup>

	· · · · · · · · · · · · · · · · · · ·	Maximum Process	Temperature
Meter Size (Inches)	Maximum Ambient Temperature	Temperature	Class
1/2	149 °F (65 °C)	239 °F (115 °C)	Т3
1	149 °F (65 °C)	248 °F (120 °C)	T3
1	95 °F (35 °C)	95 °F (35 °C)	T4
1 <sup>1</sup> /2	149°F (65 °C)	257 °F (125 °C)	Т3
1 <sup>1</sup> /2	122 °F (50 °C)	140 °F (60 °C)	T4
2	149 °F (65 °C)	257 °F (125 °C)	T3
2	149 °F (65 °C)	167 °F (75 °C)	T4
2	104 °F (40 °C)	104 °F (40 °C)	T5
3 - 4	149 °F (65 °C)	266 °F (130 °C)	Т3
3 - 4	149 °F (65 °C)	194 °F (90 °C)	T4
3 - 4	131 °F (55 °C)	131 °F (55 °C)	T5
3 - 4	104 °F (40 °C)	104 °F (40 °C)	T6
6	149 °F (65 °C)	275 °F(135 °C)	Т3
6	149 °F (65 °C)	230 °F (110 °C)	T4
6	149 °F (65 °C)	167 °F (75 °C)	T5
6	140 °F (60 °C)	140 °F (60 °C)	T6
8-60	149 °F (65 °C)	284 °F (140 °C)	T3
8-60	149 °F (65 °C)	239 °F (115 °C)	T4
8-60	149 °F (65 °C)	176 °F (80 °C)	T5
8-60	149 °F (65 °C)	149 °F (65 °C)	T6

(1) This table is applicable for E1 and KD approval codes only.

#### **Quick Installation Guide**

00825-0100-4727, Rev CC January 2013

Maximum Ambient	Maximum	process temperatur	e °F (°C) per temperat	ure class
Temperature	Т3	T4	Т5	T6
		0.5 in. sensor size		1
149 °F (65 °C)	296 °F (147 °C)	138 °F (59 °C)	53 °F (12 °C)	17 °F (-8 °C)
140 °F (60 °C)	309 °F (154 °C)	150 °F (66 °C)	66 °F (19 °C)	28 °F (-2 °C)
131 °F (55 °C)	321 °F (161 °C)	163 °F (73 °C)	78 °F (26°C)	41 °F (5 °C)
122 °F (50 °C)	334 °F (168 °C)	176 °F (80 °C)	89 °F (32 °C)	53 °F (12 °C)
113 °F (45 °C)	347 °F (175 °C)	189 °F (87 °C)	102 °F (39 °C)	66 °F (19 °C)
104 °F (40 °C)	350 °F (177 °C)	199 °F (93 °C)	114 °F (46 °C)	78 °F (26 °C)
95 °F (35 °C)	350 °F (177 °C)	212 °F (100 °C)	127 °F (53 °C)	89 °F (32 °C)
86 °F (30 °C)	350 °F (177 °C)	224 °F (107 °C)	138 °F (59 °C)	102 °F (39 °C)
77 °F (25 °C)	350 °F (177 °C)	237 °F (114 °C)	150 °F (66 °C)	114 °F (46 °C)
68 °F (20 °C)	350 °F (177 °C)	248 °F (120 °C)	163 °F (73 °C)	127 °F (53 °C)
		1.0 in. sensor size		
149 °F (65°C)	318 °F (159 °C)	158 °F (70 °C)	71 °F (22 °C)	34 °F (1 °C)
140 °F (60°C)	330 °F (166 °C)	170 °F (77 °C)	84 °F (29 °C)	46 °F (8 °C)
131°F (55 °C)	343 °F (173 °C)	183 °F (84 °C)	96 °F (36 °C)	59 °F (15 °C)
122 °F (50 °C)	350 °F (177 °C)	196 °F (91 °C)	109 °F (43 °C)	72 °F (22 °C)
113 °F (45 °C)	350 °F (177 °C)	206 °F (97 °C)	122 °F (50 °C)	84 °F (29 °C)
104 °F (40 °C)	350 °F (177 °C)	219 °F (104 °C)	134 °F (57 °C)	96 °F (36 °C)
95 °F (35 °C)	350 °F (177 °C)	231 °F (111 °C)	145 °F (63 °C)	109 °F (43 °C)
86 °F (30 °C)	350 °F (177 °C)	244 °F (118 °C)	158 °F (70 °C)	122 °F (50 °C)
77 °F (25 °C)	350 °F (177 °C)	257 °F (125 °C)	170 °F (77°C)	134 °F (57 °C)
68 °F (20 °C)	350 °F (177 °C)	269 °F (132 °C)	183 °F (84 °C)	145 °F (63 °C)
		1.5 in. sensor size		
149 °F (65 °C)	296 °F (147 °C)	159 °F (71°C)	87 °F (31 °C)	55 °F (13 °C)
140 °F (60 °C)	307 °F (153 °C)	170 °F (77°C)	96 °F (36 °C)	66 °F (19 °C)
131 °F (55 °C)	318 °F (159 °C)	181 °F (83°C)	107 °F (42 °C)	77 °F (25 °C)
122 °F (50 °C)	329 °F (165 °C)	192 °F (89 °C)	118 °F (48 °C)	87 °F (31 °C)
113 °F (45 °C)	339 °F (171 °C)	203 °F (95 °C)	129 °F (54 °C)	96 °F (36 °C)
104 °F (40 °C)	350 °F (177 °C)	213 °F (101 °C)	140 °F (60 °C)	107 °F (42 °C)
95 °F (35 °C)	350 °F (177 °C)	222 °F (106 °C)	150 °F (66 °C)	118 °F (48 °C)
86 °F (30 °C)	350 °F (177 °C)	233 °F (112 °C)	159 °F (71 °C)	129 °F (54 °C)
77 °F (25 °C)	350 °F (177 °C)	244 °F (118 °C)	170 °F (77 °C)	140 °F (60 °C)
68 °F (20 °C)	350 °F (177 °C)	255 °F (124 °C)	181 °F (83 °C)	150 °F (66 °C)
	Cc	ontinued on Next Pag	ge	

Table 13. Relation between the maximum ambient temperature, the maximum process temperature, and the temperature  $\mbox{class}^{(1)}$ 

#### Quick Installation Guide 00825-0100-4727, Rev CC January 2013

# Rosemount 8700 Series

Table 13. Relation between the maximum ambient temperature, the maximum process temperature, and the temperature  $\mbox{class}^{(1)}$ 

Maximum Ambient	Maximum	process temperatur	e °F (°C) per temperat	ure class		
Temperature	Т3	T4	Т5	T6		
		2.0 in. sensor size	-			
149 °F (65 °C)	289 °F (143 °C)	163 °F (73 °C)	95 °F (35 °C)	66 °F (19 °C)		
140 °F (60 °C)	300 °F (149 °C)	172 °F (78 °C)	104 °F (40 °C)	75 °F (24 °C)		
131 °F (55 °C)	309 °F (154 °C)	183 °F (84 °C)	114 °F (46 °C)	84 °F (29 °C)		
122 °F (50 °C)	318 °F (159 °C)	192 °F (89 °C)	123 °F (51 °C)	95 °F (35 °C)		
113 °F (45 °C)	329 °F (165 °C)	201 °F (94 °C)	134 °F (57 °C)	104 °F (40 °C)		
104 °F (40 °C)	338 °F (170 °C)	212 °F (100 °C)	143 °F (62 °C)	114 °F (46 °C)		
95 °F (35 °C)	348 °F (176 °C)	221 °F (105 °C)	152 °F (67 °C)	123 °F (51 °C)		
86 °F (30 °C)	350 °F (177 °C)	231 °F (111 °C)	163 °F (73 °C)	134 °F (57 °C)		
77 °F (25 °C)	350 °F (177 °C)	240 °F (116 °C)	172 °F (78 °C)	143 °F (62 °C)		
68 °F (20 °C)	350 °F (177 °C)	251 °F (122 °C)	183 °F (84 °C)	152 °F (67 °C)		
	3 to 60 in. sensor size					
149 °F (65 °C)	350 °F (177 °C)	210 °F (99 °C)	116 °F (47 °C)	75 °F (24 °C)		
140 °F (60 °C)	350 °F (177 °C)	222 °F (106 °C)	129 °F (54 °C)	89 °F (32 °C)		
131 °F (55 °C)	350 °F (177 °C)	237 °F (114 °C)	143 °F (62 °C)	102 °F (39 °C)		
122 °F (50 °C)	350 °F (177 °C)	249 °F (121 °C)	156 °F (69 °C)	116 °F (47 °C)		
113 °F (45 °C)	350 °F (177 °C)	264 °F (129 °C)	170 °F (77 °C)	129 °F (54 °C)		
104 °F (40 °C)	350 °F (177 °C)	266 °F (130 °C)	183 °F (84 °C)	143 °F (62 °C)		
95 °F (35 °C)	350 °F (177 °C)	266 °F (130 °C)	197 °F (92 °C)	156 °F (69 °C)		
86 °F (30 °C)	350 °F (177 °C)	266 °F (130 °C)	203 °F (95 °C)	170 °F (77 °C)		
77 °F (25 °C)	350 °F (177 °C)	266 °F (130 °C)	203 °F (95 °C)	176 °F (80 °C)		
68 °F (20 °C)	350 °F (177 °C)	266 °F (130 °C)	203 °F (95 °C)	176 °F (80 °C)		

(1) This table is applicable for N1 option codes only.

### **Quick Installation Guide**

00825-0100-4727, Rev CC January 2013

Line Size Inch (mm)	Maximum Ambient Temperature °F (°C)	Maximum Process Temperature °F (°C)	Temperature Code (T-Code)	Junction Box Orientation	Transmitter Mounting <sup>(2)</sup>
2 (50)	140 °F (60 °C)	140 °F (60 °C)	Т5	Any	Integral or Remote
2 (50)	140 °F (60 °C)	212 °F (100 °C)	T4	Any	Remote Only
2 (50)	140 °F (60 °C)	300 °F (150 °C)	Т3	Side or Down	Remote Only
3 (80)	140 °F (60 °C)	140 °F (60 °C)	Т5	Any	Integral or Remote
3 (80)	140 °F (60 °C)	212 °F (100 °C)	T4	Any	Remote Only
3 (80)	140 °F (60 °C)	300 °F (150 °C)	Т3	Side or Down	Remote Only
4 (100)	140 °F (60 °C)	140 °F (60 °C)	Т5	Any	Integral or Remote
4 (100)	140 °F (60 °C)	230 °F (110 °C)	T4	Any	Remote Only
4 (100)	140 °F (60 °C)	320 °F (160 °C)	Т3	Side or Down	Remote Only
6 (150)	140 °F (60 °C)	140 °F (60 °C)	Т5	Any	Integral or Remote
6 (150)	140 °F (60 °C)	240 °F (115 °C)	T4	Any	Remote Only
6 (150)	140 °F (60 °C)	330 °F (165 °C)	Т3	Side or Down	Remote Only
8 (200) -36 (900)	140 °F (60 °C)	140 °F (60 °C)	Т5	Any	Integral or Remote
8 (200) -36 (900)	140 °F (60 °C)	250 °F (120 °C)	T4	Any	Remote Only
8 (200) -36 (900)	140 °F (60 °C)	340 °F (170 °C)	T3	Side or Down	Remote Only

Table 14. The relation between ambient temperature, process temperature, temperature class, orientation of the junction box and flowtube mounting  $^{\left(1\right)}$ 

(1) This table is applicable for N7 option code only.

(2) Other combinations of process temperature and ambient temperature can be used with integral mounting, but it must be assured that the temperature of the mounting flange and other components comprising the electronics housing of the transmitter do not go outside the ambient temperature limits of the transmitter.

#### Table 15. Electrical Data<sup>(1)</sup>

Coil Circuit Parameters:	Um = 40V max, Imax = 500 mA,Pmax = 20 W
Electrode Circuit Parameters:	Ui = 5 V, Uo= 5 V, Io= 200 µA, Po= 1 mW

(1) This table is applicable for N7 option code only.

#### Figure 23. Rosemount 8705 Declaration of Conformity

	634	2012 W 120
EC Declar	ation o	f Conformity
NO	RFD 1000	Rev. I
We,		
Rosemount Inc. 12001 Technology Drive		
Eden Prairie, MN 55344-36	95	
USA		
declare under our sole responsibility	that the produc	t(s),
Model 870	5 Magneti	c Flowmeters
manufactured by,		
Rosemount Inc.	12	Fisher-Rosemount Flow Technologie
12001 Technology Drive Eden Prairie MN 55344.36	and 95	Ave. Miguel de Cervantes 111 Chibushus, CHIH, 31109
USA	12	Mexico
to which this declaration relates, is in Community Directives, including the	e conformity w	ith the provisions of the European nents, as shown in the attached schedule.
Assumption of conformity is based o standards and, when applicable or re as shown in the attached schedule.	n the applicatio quired, a Europ	on of harmonized or applicable technical sean Community notified body certification
	7	Mach Fler (signature)
(date of issue)		(name - printed)
	100	
	Vice	President Technology and New Products
		(function name - printed)

EMERSON. Process Management	ROSEMOUNT	Ce
	Schedule	
EC	Declaration of Conformity RFD 1006 Rev. I	
EMC Directive (20	04/108/EC)	
All Models EN 613	26-1: 2006	
PED Directive (97/	23/EC)	
Model 8705 Ma	agnetic Flowmeter with Option "PD", in Line Sizes	1.5"- 36"
Equipment wit without furthe	hout the 'PD' option is NOT PED compliant and ca r assessment	mnot be used in the EE
QS Cen Module ASME	ificate of Assessment - EC No. 59552-2009-CE-HOU H Conformity Assessment B31.3: 2008	DNV
Model 8705 wi	ith Option "PD", in Line Sizes .5" - 1.0"	
Sound I ASME	Engineering Practice B31.3: 2008	
ATEX Directive (S	94/9/EC)	
Model 8705 M	agnetic Flowmeter	
KEMA	02ATEX1302 X – Type n Certificate Equipment Group II, Category 3 G (EEx nA [L] IIC T EN 50021: 1999	3 T6)
KEMA	03ATEX2052 X - Increased Safety with Intrinsica Equipment Group II, Category 1/2 G (EEx e ia IIC T3 EN 50019: 2000 EN 50020: 2002	lly Safe Electrodes T6)
P. P. Philippine		ENV REPORT A

EMERSON. Process Management	ROSEMOUNT	C
	Schedule	
EC.	Declaration of Conformity RFD 1000 Rev. 1	
ATEX Directive (S	94/9/EC) cont a	
KEMA	06ATEX0006 – Dust Certificate Equipment Group II, Category 1 D (Ex tD A20 IP6x T105* EN 61241-0: 2006 EN 61241-1: 2004	C)
PED Notified Bod	у	
Det No Veritas Hovik,	rske Veritas (DNV) [Notified Body Number: 0575] veien 1, N-1322 Norway	
ATEX Notified Bo	odies for EC Type Examination Certificate	
KEMA Utrecht P.O. B The Ne Postbar	[Notified Body Number: 0344] seweg 310, 6812 AR Arnhem xx 5185, 6802 ED Arnhem therlands uk 6794687	
ATEX Notified Be	ody for Quality Assurance	
Det No Veritas Hovik,	rske Veritas (DNV) [Notified Body Number: 0575] veien 1, N-1322 Norway	
P.B. PMCCEMains	814/1	and approved



<section-header>         December 7, 2011         Open Particle         Open Particle         Open Particle         December 7, 2011         Open Particle         Open Particle</section-header>	ROSEA	NOU	NT C
We,       Resember line, 12001 Technology Drive Eden Prairie, MN 55344-3695 USA         declare under our sole responsibility that the product(s). <b>Model 8711 Magnetic Flowmeters</b> manufactured by,         Resember Prairie, MN 55344-3695         2001 Technology Drive 12001 Technology Drive 2001 Technology Drive 2001 Technology Drive 2001 Technology Drive 2003 Mexico         to which this declaration relates, is in conformity with the provisions of the European Community Directives, including the latest amendments, as shown in the attached schedule.         Assumption of conformity is based on the application of harmonized or applicable technical standards and, when applicable or required, a European Community notified body certificat as shown in the attached schedule.         Mark Fielde (date of issue)       Mark Fielde (mare - printed)         Vice President Technology and New Products (function name - printed)	EC Declaratio	n of	Conformity Rev. H
Resensement Inc.       12001 Technology Drive         Eden Prairie, MN 55344-3695       USA         declare under our sole responsibility that the product(s), <b>Model 8711 Magnetic Flowmeters</b> manufactured by,       and         Zool Technology Drive       and         Loog Treine, MN 55344-3695       Chinuabua, CHIH 31109         USA       Mexico         to which this declaration relates, is in conformity with the provisions of the European         Community Directives, including the latest amendments, as shown in the attached schedule.         Assumption of conformity is based on the application of harmonized or applicable technical standards and, when applicable or required, a European Community notified body certificat as shown in the attached schedule.         Mark Fleige       (apartaré)         (date of issue)       (mare - printed)         Vice President Technology and New Products       (function name - printed)	We,		
declare under our sole responsibility that the product(s), <b>Model 8711 Magnetic Flowmeters</b> manufactured by, Rosemount Inc. 12001 Technology Drive Eden Prairie, MN 55344-3695 USA to which this declaration relates, is in conformity with the provisions of the European Community Directives, including the latest amendments, as shown in the attached schedule. Assumption of conformity is based on the application of harmonized or applicable technical standards and, when applicable or required, a European Community notified body certificat as shown in the attached schedule. Mark Fieigle (date of insue) Mark Fieigle (tarte - printed) Vice President Technology and New Products (function name - printed)	Rosemount Inc. 12001 Technology Drive Eden Prairie, MN 55344-3695 USA		
Model 8711 Magnetic Flowmeters         manufactured by,         Rosemount Inc.         12:001 Technology Drive         Eden Prairie, MN 55344-3695         USA         to which this declaration relates, is in conformity with the provisions of the European         Community Directives, including the latest amendments, as shown in the attached schedule.         Assumption of conformity is based on the application of harmonized or applicable technical standards and, when applicable or required, a European Community notified body certificat as shown in the attached schedule.         Mark Fieigle       (attac of insut)         (date of insut)       (mare - printed)         Vice President Technology and New Products       (function name - printed)	declare under our sole responsibility that the	product	(s),
manufactured by,           Rosemount Inc.         Fisher-Rosemount Flow Technology           12001 Technology Drive         and         Ave. Miguel de Cervantes 111           Eden Prairie, MN 55344-3695         and         Ave. Miguel de Cervantes 111           USA         Chibuahua, CHIH 31109         Mexico           to which this declaration relates, is in conformity with the provisions of the European         Community Directives, including the latest amendments, as shown in the attached schedule.           Assumption of conformity is based on the application of harmonized or applicable technical standards and, when applicable or required, a European Community notified body certificat as shown in the attached schedule.           Maxwey         (signature)           (signature)         (signature)           (date of issue)         (signature)           Vice President Technology and New Products         (function name - printed)	Model 8711 Ma	gnetic	Flowmeters
Rosemount Inc.       and       Fisher-Rosemount Flow Technologi         12001 Technology Drive       and       Ave. Miguel de Cervantes 111         USA       Chihuahua, CHIH 31109       Mexico         to which this declaration relates, is in conformity with the provisions of the European Community Directives, including the latest amendments, as shown in the attached schedule.       Assumption of conformity is based on the application of harmonized or applicable technical standards and, when applicable or required, a European Community notified body certificat as shown in the attached schedule.         December 7, 2011       Mark Fleigle         (date of issue)       Vice President Technology and New Products	manufactured by,		
to which this declaration relates, is in conformity with the provisions of the European Community Directives, including the latest amendments, as shown in the attached schedule. Assumption of conformity is based on the application of harmonized or applicable technical standards and, when applicable or required, a European Community notified body certificat as shown in the attached schedule.	Rosemount Inc. 12001 Technology Drive Eden Prairie, MN 55344-3695 USA	and	Fisher-Rosemount Flow Technologie Ave. Miguel de Cervantes 111 Chihuahua, CHIH 31109 Mexico
Assumption of conformity is based on the application of harmonized or applicable technical standards and, when applicable or required, a European Community notified body certificat as shown in the attached schedule.	to which this declaration relates, is in conform Community Directives, including the latest a	mity wi mendm	h the provisions of the European ents, as shown in the attached schedule.
December 7, 2011 (date of insue) (date of insue) Vice President Technology and New Products (function name - printed)	Assumption of conformity is based on the ap standards and, when applicable or required, a as shown in the attached schedule.	plicatio a Europ	n of harmonized or applicable technical an Community notified body certification
December 7, 2011         Mark Fleigle.           (date of insue)         (name - printed)           Vice President Technology and New Products (function name - printed)		5	Mar Kin
Vice President Technology and New Products (function name - printed)	December 7, 2011	<u>.</u>	Mark Fleigle
	(and or anal)	Vice	(stant - printed)  resident Technology and New Products (function same - printed)

EMERSON.	ROSEMOUNT	. (
	Schedule	
	EC Declaration of Conformity RFD 1007 Rev. H	
EMC Direct	ive (2004/108/EC)	
All Mo	lels EN 61326-1: 2006	
PED Directi	ve (97/23/EC)	
Model	8711 Magnetic Flowmeter with Option "PD", in Line Sizes 1.5"- 8"	
Equip: withou	nent without the 'PD' option is NOT PED compliant and cannot be used i t further assessment	n the E
	QS Certificate of Assessment - EC No. 59552-2009-CE-HOU-DNV Module H Conformity Assessment ASME B31.3: 2008	
Model	8711 with Option "PD", in Line Sizes .15" - 1.0"	
	Sound Engineering Practice ASME B31.3: 2008	
ATEX Dire	ctive (94/9/EC)	
Model	8711 Magnetic Flowmeter	
	KEMA 02ATEX1302 X – Type n Certificate Equipment Group II, Category 3 G (EEx nA [L] IIC T3 T6) EN 50021: 1999	
	KEMA 03ATEX2052 X – Increased Safety with Intrinsically Safe Electro Equipment Group II, Category 1/2 G (EEx e ia IIC T3 T6) EN 50019: 2000 EN 50020: 2002	odes
	Part 2 of 3 5111 8	FD1007 HL

EMERSON.	ROSEMOUNT	Ce
EC	Schedule Declaration of Conformity RFD 1007 Rev. H	C.
ATEX Directive (9	4/9/EC) cont'd	
KEMA	06ATEX0006 Dust Certificate Equipment Group II, Category 1 D (Ex tD A20 IP6x T1 EN 61241-0: 2006 EN 61241-1: 2004	05°C)
PED Notified Body	y .	
Det No Veritas Hovik,	rske Veritas (DNV) [Notified Body Number: 0575] veien 1, N-1322 Norway	
ATEX Notified Bo	dies for EC Type Examination Certificate	
KEMA Utrecht P.O. Bo The Ne Postbar	[Notified Body Number: 0344] seweg 310, 6812 AR Arnhem ix 5185, 6802 ED Arnhem therlands ik 6794687	
ATEX Notified Bo	ody for Quality Assurance	
Det No Veritas Hovik,	rske Veritas (DNV) [Notified Body Number: 0575] veien 1, N-1322 Norway	

#### Figure 25. Rosemount 8721 Declaration of Conformity

EC Declarati	on of Conformity
No: RFD	1051 Rev. E
We,	
Rosemount Inc.	
12001 Technology Drive Eden Prairie, MN 55344-3695	
USA	
declare under our sole responsibility that the	e product(s),
Model 8721 Sanitar	y Magnetic Flowmeters
manufactured by,	
Rosemount Inc.	Fisher-Rosemount Flow Techn
12001 Technology Drive Eden Prairie, MN 55344 3695	and Ave. Miguel de Cervantes 111 Chibashan CHIII 1109
USA	Mexico
to which this declaration relates, is in confe Community Directives, including the latest	emity with the provisions of the European amendments, as shown in the attached sche
Assumption of conformity is based on the a standards and, when applicable or required as shown in the attached schedule.	application of harmonized or applicable tech , a European Community notified body certi
	Mile For (vignation)
(date of insue)	Mark Fleigle
	Vice President Technology and New Product (function name - orinted)
	frank franklight

# Quick Installation Guide 00825-0100-4727, Rev CC

January 2013

	Schedule EC Declaration of Conformity RFD 1051 Rev.	E
EMC Dire	tive (2004/108/EC)	
All M	dels EN 61326-1: 2006	
PED Direc	ive (97/23/EC)	
Mode	8721 Magnetic Flowmeter, line sizes greater than 1"(25mr	m)::
Equi witho	ment without the 'PD' option is NOT PED compliant and o at further assessment	cannot be used in the EE/
	QS Certificate of Assessment - EC No, 59552-2009-CE-HOU Module A Conformity Assessment Category I Equipment ASME B31.3: 2008	J-DNV
Mode	8721 Magnetic Flowmeter, in line sizes less than 1" (25mn	n):
	Sound Engineering Practice ASME B31.3: 2008	
PED Notif	ed Body	
	Det Norske Veritas (DNV) [Notified Body Number: 0575] Veritasveien 1, N-1322 Hovik, Norway	

# **Quick Installation Guide**

00825-0100-4727, Rev CC January 2013